

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 4754 Jacket with Diagonal Closure

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: fusible interfacing; lining; thin shoulder pads; 4 buttons. .

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: 1 cm for all seams.

### Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Side front right – cut 1
4. Side front left – cut 1
5. Center front right – cut 1
6. Center front left – cut 1
7. Lower back facing – cut 2
8. Back neck facing – cut 2



9. Lower front facing right – cut 2
10. Lower front facing left – cut 2
11. Front neck facing right – cut 2
12. Front neck facing left – cut 2
13. Upper sleeve – cut 2
14. Lower sleeve – cut 2
15. Upper cuff – cut 2
16. Lower cuff – cut 2
17. Strap – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front right – cut 1
4. Side front left – cut 1
5. Center front right – cut 1
6. Center front left – cut 1
7. Upper sleeve – cut 2
8. Lower sleeve – cut 2

Fusible interfacing:

1. Lower back facing – cut 1
2. Back neck facing – cut 1
3. Lower front facing right – cut 1
4. Lower front facing left – cut 1
5. Front neck facing right – cut 1
6. Front neck facing left – cut 2
7. Upper cuff – cut 2
8. Lower cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge separately, sew, and press apart princess seams on the back (sew side backs to center backs). Sew and press apart the center back seam. Sew the lower facing to the back, press towards facing, and topstitch at 0.7 cm from the seam. Sew the neckline facing to the back, press towards facing, and topstitch at 0.7 cm from the seam.
3. Sew darts on center fronts, press bulk upwards. Sew and press apart princess seams on front (serge separately and sew center fronts to side fronts).

4. **Left front:** Sew the lower facing to the front, clipping into the seam allowance near the corner. Press towards facing and topstitch at 0.7 cm from the seam. Sew the neckline facing to the front, press towards facing, and topstitch at 0.7 cm from the seam.  
**Right front:** Sew the lower facing to the front, clipping into the seam allowance near the corner, starting stitching exactly at the marked neckline seam line. Press towards facing and topstitch at 0.7 cm from the seam. Sew the neckline facing to the front, stopping exactly at the marked center seam line. Press towards facing and topstitch at 0.7 cm from the seam. Sew facings together, leaving the area between notches unstitched to form a buttonhole. Press the seam open.
5. Sew and press apart shoulder and side seams.
6. Sew and press apart the elbow sleeve seam, easing the upper sleeve and matching notches. Sew and press apart the front sleeve seam. Sew cuffs together, press the seam open. Pin the cuff to the sleeve, right sides together, and sew along the lower edge. Press the seam, fold the cuff to the wrong side, and topstitch at 0.7 cm from the sleeve hem.
7. Pin the strap pieces right sides together and sew along the long side and one short side. Trim seam allowances, turn the strap right side out, press, and topstitch at 0.7 cm from the edge. Sew the strap to the inner side of the cuff according to the markings.
8. Sew the sleeves into the armholes, matching notches and easing the upper sleeve cap. Sew in shoulder pads.
9. Assemble the lining pieces and sew facings for the neckline and hem, the same as for the main fabric. Leave an opening in the left elbow sleeve seam for turning. Pin lining to the garment, right sides together, and sew around the hem, center front, and neckline. Trim corners, clip curves, turn the garment right side out, and press. Topstitch 0.7 cm from the edge around the contour.
10. Sew the lining to the sleeve hem through the opening, press the seam. Close the opening.
11. Sew the button on the left front. Make a buttonhole on the left front, sew the inner button on the right front. Make buttonholes and sew buttons on the straps and cuffs.

Congratulations, your jacket is ready! :)