

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 4764 Shirt – blouse

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 10 buttons.



### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: Seam allowance for hem of garment – 1.5 cm, other seams – 1 cm.

### Main fabric:

1. Back - cut 1 on fold
2. Back yoke - cut 1
3. Back neck facing - cut 2
4. Front - cut 2
5. Front yoke - cut 2
6. Front neck facing - cut 4
7. Front placket - cut 2
8. Sleeve – cut 2
9. Cuff – cut 2

## 10. Pocket – cut 1

### Fusible interfacing:

1. Back neck facing - cut 2
2. Front neck facing - cut 4
3. Front placket - cut 2
4. Cuff – cut 2

### INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew a gathering stitch along upper edge of back and gather fullness. Sew yoke to back, press seam allowances towards yoke and serge. Sew yoke to front, press seam allowances towards yoke and serge.
3. Fold the upper seam allowance of the pocket to the wrong side by 1 cm and press, then fold it again according to the marked line, press and topstitch. Press side and lower seam allowances of pocket onto wrong side. Pin pocket onto left front according to markings and topstitch.
4. Press plackets in half lengthwise right side out. Sew outer edge of placket to front. Press towards placket. Fold inner edge of placket inside and stitch in the ditch.
5. Sew side and shoulder seams, press seams towards back and serge.
6. Sew shoulder seams of neck facings, press seam apart. Pin together outer facing and outer facing right sides together and sew outer edges. Start and stop sewing exactly at the marked line of seam. Clip into curves. Turn the finished facing right side out and press.
7. Sew outer facing into neckline, turn raw edge of outer facing under and stitch in the ditch.
8. Cut slit on sleeve along the marked line. Cut bias tape from main fabric (or take ready), its width should equal 4 cm and length should equal two lengths of slit +4 cm. Fold bias tape in half lengthwise and press. Press outer seam allowances towards center. Sew bias tape to slit of sleeve (pin bias tape to slit edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line).
9. Sew sleeve seam, serge and press. Sew sleeves into armholes, serge, and press.

10. Fold cuff in half lengthwise, right sides together and sew short sides. Start stitching exactly at the line which marks the seam between cuff and sleeve. Turn cuff right side out and press. Sew outer side of cuff to lower edge of sleeve. Fold inside inner side of cuff and stitch in the ditch.

11. Serge lower edge of garment, press onto wrong side and topstitch.

12. Make buttonholes on right front, sew on buttons on the left one. Make buttonholes and sew on buttons onto cuffs.

Congratulations, your blouse is ready! :)