

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4878 Blouse with Raglan Sleeves

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 1.2 cm.

Main fabric:

1. Center back – cut 1 on fold
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 1 on fold
5. Sleeve – cut 2
6. Pocket – cut 2

INSTRUCTIONS:

1. Sew the darts on the front and press the excess upward. Fold the pocket along the

- marked line with wrong sides together and press. Pin the pocket to the side front and baste along the side and lower edges. Treat it as one piece from this point on.
2. Sew the side back pieces to the center back and the side front pieces to the center front. Serge the seams and press them toward the center.
 3. Sew the sleeves to the back pieces, press toward the back, and serge. Sew the sleeves to the front pieces, press toward the front, and serge.
 4. Sew the side seams, sewing the sleeve seams at the same time. Serge and press.
 5. Cut or use ready-made bias tape 4 cm wide and equal in length to the neckline plus 5 cm. Fold the bias tape in half lengthwise with the right side out and press. Pin the bias tape to the neckline from the right side and sew. Clip into the seam allowances. Fold the bias tape to the wrong side and topstitch to the main piece along the fold. Press.
 6. Serge the hem allowances of the garment and sleeves, press to the wrong side, and topstitch.

Congratulations – your blouse are finished! :)