

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4955 Lightweight coat with hood and pockets

Recommendations on fabric: thick natural/mixed knit fabric of small stretchiness approx. 2 m (size 32-40), approx. 2.4 m (size 42-54) with a fabric width of 150 cm.

Lining approx. 2 m (size 32-40), approx. 2.4 m (size 42-54) with a fabric width of 150 cm.



You will also need: fusible interfacing, separating zipper, 2 decorative zippers, 4 buttons, 10 flat buttons for hood.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm.

Main fabric:

1. Back – cut 1 on fold
2. Side – cut 2
3. Front – cut 2
4. Back neck facing – cut 1
5. Center front facing – cut 2
6. Hem facing – cut 1 on fold

7. Stand collar – cut 2
8. Hood – cut 2
9. Hood facing – cut 2
10. Sleeve – cut 2
11. Cuff – cut 2
12. Pocket – cut 2

Lining:

1. Back lining – cut 1 on fold
2. Side lining – cut 2
3. Front lining – cut 2
4. Hood – cut 2
5. Sleeve – cut 2
6. Pocket – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Hem facing – cut 2
4. Stand collar - cut 1
5. Hood facing – cut 1
6. Cuff – cut 2
7. Pocket – cut 2

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Apply fusible interfacing.
2. Sew the front darts, pressing the bulk upward.
3. Mark the position of the pocket on the front. Mark the position of the zipper on the pocket. Cut a slit for the pocket opening and make diagonal cuts 1-1.5 cm from each end of the marked slit. Turn the seam allowances to the wrong side through the opening, straightening the edges. Pin the zipper under the opening so the teeth are visible and sew it in place. Pin the pocket to the lining with right sides together and sew, leaving an opening for turning. Clip seam allowances and trim corners. Turn the pocket right side out, straighten, and press. Topstitch the pocket onto the front along the side edges and

horizontal line, creating a flap from the lower part of the pocket.

4. Sew the side backs to the center back, pressing the seams apart. Sew the side fronts to the front and press the seams apart. Sew the shoulder seams and press them apart.

5. Sew the outer stand collar into the neckline, clip seam allowances, and press them apart.

6. Sew the shoulder edges of the center front facings and back neckline facing, pressing the seams apart. Sew the inner stand collar into the neckline, clip seam allowances, and press them apart. Attach the hem facing to the center front facings, pressing the seams apart.

7. Place the center front facing onto the front with right sides together, and sew along the center front edge, inserting the zipper, lower edge, and the edge of the stand collar. Clip into the curves, trim corners, turn the facings to the wrong side, straighten, and press.

8. Sew the sleeve seam and press the seam apart. Attach the sleeves to the armholes and press the seams.

9. Sew the cuff into a ring and press the seam apart. Fold the cuff in half lengthwise with the right side out and press. Attach the outer side of the cuff to the lower edge of the sleeve and press toward the cuff.

10. Sew the seams on the lining and set in the sleeves, leaving an opening in the left side seam.

11. Sew the lining to the center front facings and other facings. Attach the lining to the inner side of the cuff. Turn the garment right side out through the opening. Baste together the seam allowances of the stand collars and the seam allowances of the cuffs. Sew the opening closed.

12. Sew a topstitch along the lower edge to secure. Attach buttons to the pocket.

13. Sew the hood seam and press the seam apart. Attach the facing to the hood and press the seam allowances toward the facing. Sew the hood lining in the same way. Pin the hood to the lining with right sides together and sew around all edges, leaving an opening for turning. Clip into curves, trim corners, turn the hood right side out, straighten, and press. Sew the opening closed.

14. Make buttonholes along the hood neckline. Sew buttons onto the seam of the stand collar.



Model 4955

pattern from pppp.dk

Congratulations, your coat is ready! :)