

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 4967 Little coat with decorative part

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining, fusible interfacing, 2 buttons, 3 inner buttons.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve – 3 cm.

### Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Strap – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2
8. Collar – cut 2
9. Back neck facing – cut 1

10. Center front facing – cut 2
11. Pocket welt – cut 2
12. Underlay piece – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Large pocket bag – cut 2
8. Small pocket bag – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Collar - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew the center back seam. Press the seam allowances apart. Sew the side backs to center back. Press the seam apart.
3. Mark the position of the pocket. Press welt in half lengthwise on wrong sides together. Topstitch a small pocket bag onto inner side of welt. Topstitch underlay piece onto bigger pocket bag. Sew the welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward the end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto the wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together the edges of pocket bags.
4. Make and baste a box pleat on the side front, matching the triangular markings. Clip into corner. Sew center front to side front. Press the seam apart.
5. Fold under the upper, lower, and side seam allowance of the decorative piece and press. Pin the piece onto front and topstitch at 0.3-0.5 cm.

6. Sew shoulder and side seams. Press the seam apart.
7. Sew front seam on sleeve, press the seam apart. Sew elbow seam on sleeve. Press the seam apart. Sew sleeves into armholes. Press seam.
8. Make buttonholes for inner buttons on the right center front facing (button stand). Sew shoulder seams of central front facings and facings. Press the seam apart.
9. Pin together collars right sides together and sew. Start and stop stitching exactly at the marked line of the neckline seam of collar. Trim seam allowances, clip into curves, turn right side out and press.
10. Place the center front facing onto front right sides together and sew along the center front edge, sewing the upper corners up to the center line. Sew the upper collar into the neckline center front facings and facings. Sew the lower collar into self-neckline. Press the seam apart and baste together.
11. Sew seams on lining, leaving an opening in left side seam.
12. Sew lining to the central front facings and to facing. Sew lower edge of lining to hem of garment. Sew lining to hem of sleeve. Turn right side out through the opening. Sew the opening closed.
13. Serge two button loops on the right front. Sew on buttons on the left one. Sew on inner buttons.

Congratulations, your coat is ready! :)