

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5011 Blazer with One Button

Recommendations on fabric: suiting fabric.

You will also need: fusible interfacing, lining; 1 button.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: 2 cm on garment hem; sleeve hem; all other seams 1 cm.

Main fabric:

1. Pocket welt (valance) – cut 2
2. Back – cut 2
3. Back neck facing – cut 1 on fold
4. Front – cut 2
5. Center front facing – cut 2
6. Sleeve – cut 2

Lining:

1. Sleeve – cut 2
2. Back – cut 2
3. Front – cut 2
4. Pocket sacking – cut 2

Fusible interfacing: front facings, back neck facing, fronts. Apply interfacing to wrong side of front facings, back neck facings, fronts.

INSTRUCTIONS:

1. Sew back and front darts, press toward center. Sew center back seam and press open.
2. Welt pockets: Apply a strip of fusible interfacing 4 cm wide to the wrong side along the pocket marking. Place pocket facings on front, right sides together. Pin along the pocket entrance marking and sew. Cut the front between stitches, snipping diagonally toward stitch ends. Press seam allowances apart. Fold facings onto the wrong side through the slit to make a neat frame, then tack. Pin the pocket bag to the wrong side on the lower frame, fold the bag upward, and topstitch the bag from the right side of the front, catching the pocket bag. Press the bag downward. Lay the second edge of the bag on the wrong side of the pocket and topstitch it from the right side along the seam joining the upper facing. Turn small triangles at slit ends onto the wrong side and topstitch neatly between the upper and lower stitch ends. Stitch facings' open edges.
3. Sew shoulder and side seams. Press seams open.
4. Sew front facings to back neck facing at shoulder seams. Press seams open.
5. Pin front facing to front and neckline, right sides together, and sew. Clip into curves and trim corners. Understitch and press toward the wrong side of garment.
6. Serge or finish garment's lower edge and press along hemline.
7. Sew sleeve seams. Press seams open. Make a gathering stitch along the sleeve cap for ease. Sew sleeves into armholes, matching marks and easing along sleeve caps.
8. Sew in shoulder pads.
9. Sew darts on lining front and back, sew lining seams. Sew the lining to sleeve hems, and to outer edges of front facings and back neck facing. Serge the lower edge of lining, turn onto wrong side, and topstitch.
10. Make a buttonhole on the right front, sew button on the left. Topstitch garment as suggested in the diagram, if desired.
Congratulations – your blazer are finished! :)