

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5079 Classic Women's Blazer

Recommendations on fabric: wool of 150 cm width.

You will also need: lining of 140 cm width; fusing of 0.90 m and 140 cm width; 4 buttons of 20 mm diameter, shoulder pads.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: 1 cm for all seams.

Main fabric:

1. Back part – 2 pieces
2. Front part – 2 pieces
3. Upper sleeve – 2 pieces
4. Lower sleeve – 2 pieces
5. Collar – 2 pieces
6. Flap – 2 pieces
7. Frame – 4 pieces

8. Front band – 2 pieces
9. Back neckline facing – 1 piece

Lining:

Cut front parts excluding front bands' widths. Cut lower sleeves with seam allowance only. Cut back part excluding the width of back neckline facing (folded in the middle). Warp goes parallel to fabric's bending that results into free-fit pleat of nearly 1 cm depth.

1. Sacking – 4 pieces
2. Flap – 2 pieces

Fusing: apply the fusing additionally to wrong side of back hem.

INSTRUCTIONS:

1. Apply fusible interfacing to the wrong side of front bands, inner collar, flaps, and back neckline facing.
2. Sew front darts and press them open. Cut seam allowances along pocket openings. Tack pocket openings with crossed stitches, making sure they align perfectly.
3. Sew side seams.
4. Construct double-welt flap pockets on the front piece: sew flap pairs (one fabric and one lining) along side and lower edges. Turn right side out and topstitch edges. Fuse a 4 cm wide strip to the wrong side of the front above the pocket marking. Place two pocket facings right sides together on the front, pin along the pocket marking, and stitch (the lengthwise edges of the facings should align with the center line of the pocket marking). Cut the opening between the stitching lines and diagonally into the corners, being careful not to cut into the facings. Press seam allowances towards the inside. Turn facings through to the wrong side to form a clean frame, then baste (facing folds should meet at the center of the pocket opening). Topstitch along the seam. Fold the small triangles at the corners to the wrong side and stitch them to the facings from one end of the topstitching to the other, stitching together at the side of the facing. Insert the raw edge of the flap between the facings and stitch along the upper seam. On the wrong side, attach pocket bags to the seam allowances of the flap seam and the lower facing seam. Trim, align, and sew the pocket bags together.
5. Sew back darts and press them open. Sew the center back seam. Sew shoulder seams.
6. Sew the inner collar to the neckline. Sew shoulder seams of the back facing and front

bands. Sew the outer collar to the neckline of the facing and front bands. Press seam allowances open and clip curves.

7. Place the outer collar joined with front bands right sides together with the garment. Sew along the front edges, collar, and armholes. Turn right side out and press. Sew the outer collar seam allowance to the neckline seam allowance. On the right side, turn the edges, collar, and armholes out and baste.
8. Apply fusible interfacing to the wrong side of sleeve hems. Sew upper sleeves to under sleeves, press seam allowances open, and turn the sleeves right side out. Press hem allowances to the wrong side.
9. Ease sleeve caps slightly between notches and gather to fit the armhole. Moisten the fabric and steam the gathers. Pin the sleeves to the garment, matching notches. Sew sleeves in place. Sew shoulder pads.
10. Create a back pleat in the lining and secure it below the neckline and a few centimeters above the hem. Sew darts in the lining pieces. Assemble the lining in the same way as the outer garment, leaving a 20 cm opening in one of the sleeve elbow seams. Place the lining right sides together with the garment, aligning along the center back and shoulder seams. Sew the lining to the garment along front edges and neckline. Form a pleat at the hem and sew the lining to the hem edge. Turn the garment right side out through the opening in the sleeve. Sew the sleeve opening closed.
11. Make buttonholes on the right front. Sew buttons to the left front.

Congratulations, your blazer is ready! :)