

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5158 Denim blazer

Recommendations on fabric: Denim or similar fabric.

You will also need: Fusible interfacing; 7 buttons.



CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam Allowance: 1 cm on all seams, hem – 3 cm.

Main fabric:

1. Middle back part – 2 pieces
2. Side back part – 2 pieces
3. Back yoke – 1 folded piece
4. Center front part – 2 pieces
5. Middle front part – 2 pieces
6. Side front part – 2 pieces
7. Front yoke – 1 folded piece
8. Front band – 2 pieces
9. Sleeve – 2 pieces
10. Collar – 2 pieces
11. Flap – 4 pieces
12. Off-set welt – 2 pieces

13. Back facing – 1 folded piece
14. Lower pocket – 2 pieces

Lining:

14. Lower pocket – 2 pieces
15. Upper pocket – 4 pieces

Fusible interfacing:

1. Outer collar – 1 piece
2. Front band – 2 pieces
3. Flap – 1 piece
4. Off-set welt – 2 pieces
5. Back facing – 1 folded piece

INSTRUCTIONS:

1. Apply the fusible interfacing to wrong side of outer collar, front bands, upper flap, off-set welt, back facing.
2. Stitch back middle/relieve seams, neaten them. Press middle seam toward left side, press relieves toward middle line. Topstitch seams at 2 mm.
3. Stitch back yoke to back part right sides together. Press the seam toward the yoke and topstitch at 2 mm.
4. Stitch middle front part to center/side front parts. Press the seam joining middle/front parts toward front edges, press the seam joining middle/side parts sidewise. Topstitch seams at 2 mm.
5. Cut slit pockets with off-set welts into front part: press off-set welt along the center right side out. Apply Fusible interfacing stripe of 2 cm width on wrong side of front part (above pocket marking). Lay offset welts and fabric lower pocket on front part right sides together, pin along pocket entrance marking and stitch (lengthwise edges of facings must coincide with middle line of pocket marking). Cut front part between stitches, diagonally at stitch ends. Do not cut through off-set welts and sackings! Press seam allowances apart. Turn off-set welts and sackings into wrong side through, then tack. Lay lower sacking on front part's wrong side on the welt (sacking looks up); topstitch the welt on right side along joining seam catching the sacking. Press the sacking downward. Turn small triangles at slit ends into wrong side and stitch strictly to facings between upper stitch ends and lower stitch ends. Cut sackings, adjust, and stitch them. Topstitch pocket entrance at 2 mm.

6. Lay flaps right sides together, overstretch alongside/lower edges, turn right side out, press and topstitch at 2 mm. Lay the flap on front yoke's right side and coincide flap's open edge and yoke edge; lay upper sacking on the flap; tack all layers together. Lay lower sacking on lower front part's right side. Stitch the flap and sackings. Stitch the yoke to wrong part. Turn sackings inside, adjust them and stitch together. Slash the seam near the pocket. Press joining seam toward the yoke and topstitch it.

7. Stitch side/shoulder seams. Press seams toward the same direction and topstitch at 2 mm.

8. Stitch inner collar into neckline. Stitch shoulder seams of back neckline facing and front bands. Stitch outer collar into facing's/front bands' neckline. Press allowances apart and slash at rounding's.

9. Lay outer collar joint with front bands on the garment right sides together and overstretch front edgings and the collar, then turn right side out and press. Fold outer collar's edge under and topstitch on the seam joining inner collar. Topstitch front edgings and the collar at 2 mm.

10. Stitch sleeve seam, press toward the same direction and topstitch at 2 m from the seam. Stitch sleeves into armholes, press seams toward the garment and topstitch at 2 mm.

11. Press jacket/sleeve hems into wrong side, fold edges under and topstitch along inner edges.

12. Make buttonholes into right front edging, sew buttons on the left one. Sew buttons on flaps.

Congratulations, your blazer is ready! :)