

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5161 Blazer in waterproof fabric

Recommendations on fabric: whipcord.

You will also need: lining, 4 buttons of 20 mm Diameter, 6 buttons of 12 mm diameter, shoulder pads.



CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Center front part – 2 pieces
2. Side front part – 2 pieces
3. Center back part – 2 pieces
4. Side back part – 2 pieces
5. Upper sleeve – 2 pieces
6. Lower sleeve – 2 pieces
7. Collar – 2 pieces
8. Front band – 2 pieces
9. Off-set welt – 2 pieces

Lining:

10. Center back part – 2 pieces

11. Center front part – 2 pieces
12. Side back part – 2 pieces
13. Side front part – 2 pieces
14. Upper sleeve – 2 pieces
15. Lower sleeve – 2 pieces
16. Sacking – 4 pieces

INSTRUCTIONS:

1. Stitch middle back seam, darts, front/back relieves excluding pocket entrances.
2. Overstitch off-set welts along short edges, turn details right side out and press bindings. Make decorative stitch at 1 cm along welt's edges. Coincide welt's open edges and center front relieves edge (the welt lies on center front part's right side), welt's upper edge coincides the notch. Lay upper sacking on the welt and tack all layers. Lay lower sacking on side front part's right side. Stitch off-set welt and sackings. Stitch front relieves. Fold sackings inside, adjust and stitch together. Topstitch welt's short edges on front part along decorative stitching.
3. Stitch side/shoulder seams.
4. Overstitch the collar along ends and fly collar, turn the detail right side out and press. Tack the collar to the neckline right sides together.
5. Stitch sleeve seams and press them apart. Stitch sleeves into armholes. Press sleeve hems into wrong side.
6. Sew shoulder pads.
7. Stitch lining details in the same way as fabric ones excluding 20 cm segment in one of outside sleeve seams. Stitch front bands to the lining. Lay the lining on the garment right sides together coinciding along middle back line and shoulder seams. Overstitch the garment with the lining along front edgings and neckline. Make lapping pleat along lower part and stitch the lining to hem edge. Turn the garment right side out through unstitched segment into the sleeve, then stitch segment's edges together. Sew lining sleeve hems to fabric sleeve hems allowances.
8. Make buttonholes into right edging, sew buttons on left one.

Congratulations, your blazer is ready! :)



Model 5161

pattern from pppp.dk