

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5237 Reversible robe with shawl collar

Recommendations on fabric: thick silk or cotton material.

You will also need: toweling fabric with pattern, toweling fabric without pattern, iron-on interfacing.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm.

Main fabric:

1. Back – 1 folded piece
2. Pocket bag – 2 pieces
3. Bust pocket bag – 2 pieces
4. Front – 2 pieces
5. Belt – 1 piece
6. Sleeve – 2 pieces

Trimming fabric:



1. Back – 1 folded piece
2. Pocket – 2 pieces
3. Pocket welt – 1 folded piece
4. Front – 2 pieces
5. Belt – 1 piece
6. Sleeve – 2 pieces

INSTRUCTIONS:

1. Press interfacing onto the wrong side of the pocket welt. Stitch the short ends of the welt and turn it right side out. Topstitch the welt. Apply a piece of interfacing to the wrong side of the front at the pocket opening.
2. Place the welt and the upper pocket bag right sides together along the pocket opening and pin. Stitch from the wrong side along the guide lines to form a rectangle. Cut the pocket opening and clip diagonally 1–1.5 cm from each end. Press the seam allowances open, then pull the welt and pocket bag through the opening to the wrong side. Baste and press the pocket opening. Place the lower pocket bag on the wrong side above the welt, facing upward, and topstitch the welt from the right side of the garment, catching the lower pocket bag. Press the pocket bag downward and stitch it to the upper pocket bag.
3. Sew the side seams, leaving an opening for the pocket entrance. Sew the pocket bags to the garment and stitch them together.
4. Sew the shoulder seams up to the corners. Clip the seam allowances diagonally at the corners. Sew the center seam of the collar. Sew the collar to the neckline and press the seam allowances open.
5. Sew the sleeve seams, then set the sleeves into the garment.
6. Press the hem allowance to the wrong side, fold it under, and topstitch.
7. Sew the lining (inner layer) in the same way as the outer garment, but without pockets. Place the two layers right sides together and stitch around the front edges and collar. Turn the garment right side out. Adjust the collar seams and topstitch along the seam lines. Topstitch along the front opening close to the edges. Fold the sleeve hem allowances inside and stitch, securing both layers.
8. Sew the belt by placing the pieces right sides together. Turn the belt right side out through the open edge and topstitch.

Congratulations – your robe are finished! :)