

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 5258 Hooded bathrobe

Recommendations on fabric: light material with nap/pil.

You will also need: silk tape 4 cm in width.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm.

### Main fabric:

1. Back – 1 folded piece
2. Pocket – 2 pieces
3. Front (with integrated hood) – 2 pieces
4. Belt – 1 piece
5. Sleeve – 2 pieces

### INSTRUCTIONS:

1. Fold the pocket integrated facing to the right side and sew the side seams. Turn right side out. Press the pocket seam allowances to the wrong side. Topstitch the pocket

opening and then topstitch the pocket to the garment.

2. Sew the center seam of the hood. Press the seam allowances open and topstitch them. Turn the hood right side out and sew the top cross seam.
3. Clip the seam allowances between the shoulder seams and the hood 1 cm from the ends of the darts. Cut into the centers of the darts for about 3 cm. Sew the shoulder seams, stopping at the dart points. Press the seam allowances open.
4. Sew the hood to the neckline between the darts. Sew the hood and front darts together, trim the excess fabric, and neaten the seams. Topstitch the seam allowances toward the back below the hood seam.
5. Sew the side seams.
6. Press the hem to the wrong side and topstitch. Pin the tape right sides together with the garment along the center front edges and hood edge, and stitch 1 cm from the edge. Turn the tape to the inside, folding the edges under, and topstitch from the right side along the seam.
7. Sew the sleeve seams. Finish the sleeve hems in the same way as the front and hood edges. Set the sleeves into the garment.
8. Sew the belt and topstitch it.

Congratulations – your bathrobe are finished! :)