

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5870 Lightweight Jacket with 3/4 Sleeves

Recommendations on fabric: natural/mixed thick fabrics, e.g. denim.

You will also need: fusing, 6 buttons.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: on hem of the garment – 3 cm, all other seams – 1 cm.

Main fabric:

1. Back part – 1 detail
2. Back yoke – 1 detail
3. Front part yoke – 2 details
4. Central front part – 2 details
5. Side front part – 2 details
6. Sleeve – 2 details
7. Collar – 2 details



8. Cuff – 2 details
9. Off-set welt – 2 details
10. Lining of pocket – 4 details

Fusing:

1. Collar – 1 detail
2. Cuff – 2 details
3. Off-set welt – 2 details
4. One-piece panel yokes of front part and central front part

INSTRUCTIONS:

1. Apply fusible interfacing to the one-piece front panels, front yoke panels, collar, off-set welts, and cuffs.
2. Place the top collar and undercollar right sides together. Stitch along the ends and outer edge, starting and ending exactly at the marked collar seam line. Trim seam allowances, turn right side out, straighten, and press the collar.
3. Fold the off-set welt in half lengthwise, right sides together, and stitch along the short edges. Trim corners, turn right side out, and press. Topstitch the short and one long side. Attach one pocket lining to the off-set welt.
4. Place the second pocket lining on the right side of the side front, and the welt with lining on the central front, right side down, aligning notches. Stitch the linings to the seam allowances of the pocket opening. Serge the princess seams of the front part together with the vent seam allowances.
5. Sew the princess seams, including the pocket lining, up to the vent. Press the seam allowances toward the center. Sew the pocket linings together and serge. Topstitch the princess seam on the right side at 0.2 cm. Topstitch the short ends of the welt onto the side front.
6. Press the vent allowance of the side front in half. Fold the vent so that the central part overlaps and secure with a stitch at the base of the vent.
7. Make a box pleat on the back. Attach the back yoke to the back, press seam upwards toward the yoke, and topstitch 0.2 cm from the seam. Do the same for the front yoke.
8. Serge the edge of the one-piece panel, turn it onto the right side of the front, and stitch the top corner from the fold down to the center line. Stitch the lower corner

exactly along the marked hem line. Clip corners, turn right side out, press, and topstitch the panel, catching the inner pocket lining.

9. Sew shoulder and side seams. Press seam allowances open and serge.
10. Attach the undercollar to the neckline. Turn the seam allowance of the top collar inward and topstitch in the collar joining seam.
11. Fold the cuffs right sides together and stitch along the short edges and the angled end.
12. Serge sleeve edges and sew up to the marked slit. Press seam allowances open and press the slit. Topstitch along the slit edge. Attach the top cuff to the sleeve hem. Fold the top edge of the lower cuff 1 cm inward and topstitch into the seam of the upper cuff. Topstitch along the cuff contour.
13. Sew the sleeves into the armholes and press seam allowances.
14. Serge the garment hem. Stitch the lower corners of the vents exactly along the marked hemline. Topstitch the hem along the serged edge.
15. Topstitch 0.2 cm from the edge along the button placket and collar line.
16. Make buttonholes on the right front, sew buttons on the left front. Make buttonholes and sew buttons on the cuffs.

Congratulations – your jacket are finished! :)