

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

5912 Jersey blazer with hood

Recommendations on fabric: knitted fabric of low or middle stretchiness

You will also need: fusible interfacing, 3 buttons, cord for hood, two caps for cord



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowance: on hem of the garment – 4 cm, on hem of sleeve, hood edge and top edge of pocket – 2 cm, all other seams – 1cm.

Main fabric:

1. Central back part - 2 details
2. Side back part - 2 details
3. Central front part - 2 details
4. Side front part - 2 details
5. Upper sleeve part – 2 details
6. Lower sleeve part – 2 details
7. Hood – 2 details
8. Buttonstand – 2 details
9. Pocket – 2 details

Fusible interfacing:

1. Buttonstand – 2 details

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Apply fusible interfacing to buttonstand.

2. Overstitch front stand edge and hem line with buttonstand. Sew seam from top point of front stand up to relief seam. Turn buttonstand onto the right side and press. Sew relief edges on front part. Stitch the hem allowance of side front part to buttonstand. Press seams to central part, serge and topstitch at 0.5- 0.7 cm off the seam.

3. Sew relief edges on the back part. Press seams to middle seam, serge and topstitch. Sew the middle edge of the back part. Press seam onto left side, serge and topstitch.

4. Sew shoulder and side seams. Press seams to back part and serge. Topstitch shoulder seams at 0.5 - 0.7 cm off the seam.

5. Mark and serge holes on hood, having applied fusing to them beforehand. Sew hood details. Press seam onto left side, serge and topstitch. Serge hood edge allowance, turn inside and topstitch. Sew the hood into the neckline. Slash seam near shoulder seam. Serge seam at level of back part neckline and topstitch onto the neckline. Serge shoulder edge of buttonstand. Overstitch the front part neckline with buttonstand.

6. Sew elbow edge of sleeve. Serge, press and topstitch onto top part of sleeve. Sew front sleeve seam. Serge and press to the top part. Sew the sleeve in. Press seam towards sleeve and serge.

7. Serge the hem of the garment, serging outer edge of buttonstand at the same time. Tack shoulder edge of buttonstand to shoulder seam. Press the hem onto the wrong side. Topstitch buttonstand and hem at 3.5 cm off the edge. Start and finish the seam near the shoulder seam.

8. Serge upper edge of pocket, turn inside and topstitch. Press the side and lower sides of pocket inwards. Mark pocket location on front part and topstitch the pocket. 9. Serge buttonholes on the right front part sew buttons on left front part. Run the cord through the hood and fix caps.



Model 5912

pattern from pppp.dk

Congratulations, your blazer is ready! :)