

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2244 Denim Trousers with Button Closure

Recommendations on fabric: natural/mixed denim (jeans fabric).

You will also need: lining; fusible interfacing; 6 shank buttons.

### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm, seam allowance for hem 5 cm, upper seam allowance of back pocket – 3 cm.

### Main fabric:

1. Center front half – cut 2
2. Side front half – cut 2
3. Side – cut 2
4. Back half – cut 2
5. Front center facing – cut 1
6. Side front facing – cut 2

7. Back facing – cut 1
8. Button catch – cut 2
9. Back pocket – cut 2

Lining:

1. Pocket bag – cut 2

Fusible interfacing:

1. Front center facing – cut 1
2. Side front facing – cut 2
3. Back facing – cut 1
4. Button catch – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing to the corresponding pieces, including the one-piece facings of the center front halves.
2. Sew darts on the back halves, pressing bulk towards the center.
3. Fold under the upper seam allowance of the back pocket to the wrong side and press. Turn under again and topstitch. Serge pocket edges, press seam allowances to the wrong side. Pin the pocket onto the back half according to markings and topstitch.
4. Pin the pocket bag to the front side half, right sides together, and sew the upper edge. Turn the pocket bag to the wrong side, straighten, and press. Sew a double decorative stitch along the upper edge. Pin the front side half to the side, sew the lower edge of the pocket bags, and serge. Baste pieces together along the side edge and the princess seam edge.
5. Serge the princess seam edges on the center front and side front parts. Sew the princess seam from the fly piece down to the hem. Press towards the center and sew a double decorative stitch along the seam. Press the one-piece facing for the closure to the wrong side. Serge all edges of the button catch. Press the button catch in half lengthwise, right side out. Pin the button catch to the side front at the closure area and sew the outer side. Press seam allowances onto the button catch.
6. Sew side seams, press seams towards the back, and serge. Sew a double decorative stitch along the seam. Sew the inside leg seams, serge, and press. Sew the center seam on the front halves and on the back halves with a double stitch, press seam

open, and serge.

7. Serge the lower edge of the center front facing. Fold the one-piece facings for the closure to the right side and sew the short edges of the center facing to them, press seams open. Sew the upper edge of the center front. Fold the closure and the facing to the wrong side, straighten, and press. Sew the front side facings to the back facing, press seams open, and serge the lower edge. Pin the facing to the upper edge of the pants, right sides together. Fold the button catches to the right side and sew the shorter edges of the facing to them. Sew the upper edge and continue sewing along the upper corners of the button catch. Trim corners, turn the facing right side out, and press. Sew a double decorative stitch along the upper edge. Sew a double decorative stitch line along the edge of the fly piece. Stitch-in-the-ditch the longer seam allowance of the inner side of the button catch into the seam. Place the right side of the closure over the left part, matching the line that marks the finished closure edge, and topstitch the center part onto the button catch with a double stitch.
8. Serge the hem allowance, press to the wrong side, and topstitch with a double decorative stitch.
9. Make buttonholes on the center front halves of the pants and sew buttons onto the button catches.

Congratulations – your trousers are finished! :)