

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2453 Denim Jumper Dress with Zip Closure

Recommendations on fabric: natural/mixed jeans fabrics.

You will also need: fusible interfacing; 1 separating zipper; lining.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm; seam allowance for hem of garment – 2.5 cm.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Upper side front – cut 2
5. Side 1 front – cut 2
6. Side 2 front – cut 2
7. Lower side front – cut 2



8. Back facing – cut 1
9. Front facing – cut 2

Lining:

1. Pocket bag – cut 2

Fusible interfacing:

1. Back facing – cut 2
2. Front facing – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew the side back pieces to the center back. Press the seam allowances toward the center and serge. Sew a decorative topstitch 0.5 cm from the seam.
3. Sew the center back seam. Serge the seam allowances and press them toward the left.
4. Sew the upper front to Side Front 1. Serge the seam allowances and press them upward. Sew Side Front 2 to the lower edge of Side Front 1. Serge the seam allowances and press them downward. Sew decorative topstitching along the seams of the side front pieces. Sew the pocket lining to the lower edge of the side front, turn the lining to the wrong side, and press. Sew a decorative topstitch along the pocket opening. Pin the lower front piece to Side Front 2, matching the pocket opening lines. Sew the lower edges of Side Front 2 and the pocket bag together. Serge the seam allowances. Slipstitch the pocket along the side edge and the princess seam.
5. Serge the center front edges. Insert the zipper. Sew a decorative topstitch 0.5 cm from the zipper. Sew the side front to the center front. Press the seam allowances toward the center and serge. Sew a decorative topstitch 0.5 cm from the seam.
6. Sew the side and shoulder seams. Press the seam allowances toward the back and serge.
7. Sew the shoulder and side seams of the front facing and back facings. Press the seam allowances open and serge the outer edge. Pin the facings to the garment, right sides together, and sew the neckline. Sew the armholes in two steps: first the back armhole, then the front armhole. Clip the seam allowances, turn the facing to the wrong side, shape, and press. Slipstitch the facing to the garment along the side seams and zipper tape. Sew decorative topstitching along the neckline and armholes.
8. Serge the lower edge of the dress, press it to the wrong side, and topstitch.

Congratulations – your dress are finished! :)