

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2183 Shirt with Insert

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 9 buttons.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: seam allowance for hem of garment – 2 cm; other seams – 1 cm.

Main fabric:

1. Center back – cut 1 on fold
2. Side back – cut 2
3. Center upper front – cut 2
4. Center lower front – cut 2
5. Side front – cut 2
6. Sleeve – cut 2
7. Cuff – cut 4

8. Placket – cut 2
9. Stand collar – cut 2
10. Collar – cut 2

Fusible interfacing:

1. Placket – cut 2
2. Stand collar – cut 1
3. Cuff – cut 2
4. Collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, serge the seam, and press towards the center.
3. Make and topstitch tucks on the front, pressing bulk away from the center. Sew center fronts together, serge, and press towards the bottom. Sew side fronts to the front, serge seams, and press towards the center.
4. Press the placket in half lengthwise, right side out. Sew the outer edge of the placket to the center front, pressing seam allowances onto the placket. Fold under the edge of the inner placket and stitch in the ditch.
5. Sew shoulder seams, press towards the back, and serge.
6. Pin the upper collar to the lower collar, right sides together. Sew the collar ends and collar fall. Trim seam allowances and corners. Turn the collar right side out, straighten, and press. Pin stand collar pieces together, right sides facing, sandwiching the finished collar between them. Match notches and sew, including the ends of the stand collar. Start and stop sewing exactly at the marked seam line between the stand collar and the garment. Turn the finished collar right side out and press. Sew the upper stand collar with the collar into the neckline, fold under the raw edge of the lower stand collar, and stitch in the ditch along the seam of the upper stand collar.
7. Sew side seams, press towards the back, and serge.
8. Sew a gathering stitch along the sleeve cap and gather fullness. Sew sleeve seams, serge, and press towards the back. Insert sleeves into armholes, serge, and press.

9. Sew cuffs into a ring, press seams open. Pin cuffs pairwise, right sides together, and sew along the upper edge. Turn cuffs right side out and press. Pin the right side of the cuff to the wrong side of the sleeve and sew. Serge. Fold the cuff upward, covering the seam.
10. Turn the hem under twice at 1 cm and topstitch.
11. Make buttonholes on the right placket and on the stand collar. Sew buttons on the left placket and collar. Attach buttons to cuffs through to the sleeve.

Congratulations – your shirt are finished! :)