

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.


2192 Blouse with gathers

Recommendations on fabric:
natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing.

CUTTING:

The word, "beam" used on some patterns means "straight of grain".
Some pieces will be cut on the fold, this is noted on the pattern piece.
Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Main fabric:

1. Back – cut 1 on fold
2. Front yoke – cut 2
3. Front – cut 1 on fold
4. Sleeve – cut 2
5. Back neck facing – cut 1
6. Front neck facing – cut 2

Fusible interfacing:

1. Back neck facing – cut 1
2. Front neck facing – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing to the neckline facings and to the one-piece center front facing of front yoke.
2. Sew shoulder seams, press seams towards back and serge.
3. Sew shoulder seams of neck facings, press seam apart. Serge outer edge. Serge the vertical edge of the one-piece center front facing of the front yoke. Sew the facing to the edges of center front facing. Fold the center front facing and the facing onto the right side and sew the neckline. Turn facing under, straighten, press. Pin together yokes right sides together and sew the center seam from bottom to the mark, press seam apart. Topstitch center front facing into the main piece along the inner edge, topstitch facing at 0.5-0.7 cm from the neckline edge.
4. Sew a gathering stitch along upper edge of front and gather fullness. Sew front yoke to front, press towards top and serge.
5. Sew side seams, press seams towards back and serge.
6. Sew sleeve seam, serge, and press. Sew sleeves into armholes, serge, and press.
7. Press lower edge of garment and lower edge of sleeve onto wrong side at 1 cm, then at 1.5 cm and topstitch.

Congratulations, your blouse is ready! :)