

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.


2271 Cosy pants

Recommendations on fabric: natural/mixed knit fabric of small/medium stretchiness.

You will also need: elastic tape.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm, seam allowance along the hem 2 cm.

Main fabric:

1. Back half – cut 2
2. Front half – cut 2
3. Belt – cut 1
4. Pocket bag – cut 2
5. Side – cut 2

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Pin pocket bag onto front half and sew pocket opening. Turn pocket bag onto the wrong side, topstitch seam allowances onto pocket bag at 0.1 cm and press.
2. Pin the front half onto the side according to markings. Sew pocket bag to side, serge. Baste pocket bag to front half along the upper and side edges.
3. Sew the center seam on back halves, press towards left and serge. Sew center seam on front halves, press towards left and serge.
4. Sew side seams, seam allowances press towards back and serge. Sew the inside leg edges, seam allowances press towards back and serge.
5. Sew waistband into a ring, press seam apart. Press belt in half lengthwise right side out. Measure the required length of the elastic tape and sew into ring. Insert elastic band into the belt, slipstitch according to markings. Sew belt to the pants, serge. The belt seam is placed at the left side seam.
6. Serge hem of pants, press onto wrong side and topstitch.

Congratulations, your pants are ready! :)