

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2546 Blouse with winged sleeves

Recommendations on fabric: natural/mixed fabrics suitable for dresses or blouses.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm; seam allowance along the back neckline and along the front neckline – 0 cm, seam allowance for hem of garment – 2.0 cm.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Back sleeve - cut 2
4. Front sleeve - cut 2

INSTRUCTIONS:

1. Sew darts on front, press bulk towards top.
2. Sew right shoulder seam, press seams towards back and serge.

3. Cut (or take ready) a bias tape, its length should equal the length of the neckline + 4 cm. Fold bias tape in half lengthwise right side out and press. Unfold the piece, press edges towards the fold and again press in half. Sew bias tape to neckline (pin bias tape to neckline edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line). In the corner of the neckline finished with bias tape, make a vertical tuck, and topstitch it vertically to create a sharp corner.
4. Sew left shoulder seam, press seams towards back and serge.
5. Sew side seams, press seams towards back and serge.
6. Serge the lower edges of sleeves, press onto wrong side and topstitch. (You may also finish the hem of sleeve with thin rolled hem. Trim away the seam allowance along hem in this case.) Pin back sleeve onto front sleeve, matching notches, and baste together along the sleeve cap. Sew sleeve seam, press seams towards back and serge.
7. Sew sleeves into armholes, serge, and press.
8. Fold under the hem of garment two times at 1 cm onto wrong side and topstitch.

Congratulations, your blouse is ready! :)