

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2816 Wrap Blouse with Stand Collar

Recommendations on fabric: natural/mixed fabrics suitable for blouses with elastane.

You will also need: fusible interfacing; 4 buttons.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 1.5 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Front neck facing – cut 2
4. Back neck facing – cut 1
5. Collar – cut 1
6. Sleeve – cut 2
7. Cuff – cut 2

Fusible interfacing:

1. Front neck facing – cut 2
2. Back neck facing – cut 1
3. Collar – cut 1
4. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew front darts (if the size includes them), press the bulk toward the top.
3. Sew shoulder seams, press toward the back, and serge.
4. Fold the collar in half lengthwise, right sides together, and sew corners. Trim seam allowances, turn the piece right side out, straighten, and press. Sew the collar into the neckline.
5. Sew shoulder seams of facings, press seams open. Serge the outer edge. Pin the facing to the garment, right sides together, and sew the neckline. Clip curves, fold the facing to the wrong side, and press. Baste the facing to the garment along shoulder seams.
6. Place the right front over the left front and baste together along the side edge. Sew side seams, press toward the back, and serge.
7. Serge sleeve edges separately. Sew the sleeve seam from the top down to the slit mark, press seam allowances open. Sew a fastening stitch along the slit at 0.3 cm from the edge.
8. Sew sleeves into armholes, press seam allowances, and serge. Sew a gathering stitch along the lower edge of the sleeve and gather fullness.
9. Fold the cuff in half lengthwise, right sides together, and sew short sides. Turn the cuff right side out, straighten, and press. Sew the outer side of the cuff to the sleeve, fold the inner seam allowance inside, and topstitch along the seam of the outer cuff.
10. Serge the lower edge of the garment, press to the wrong side, and topstitch.
11. Make buttonholes on the cuffs and sew on buttons.
Congratulations – your blouse are finished! :)