

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.


Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2830 T-shirt with Front Draping

Recommendations on fabric: soft natural/mixed knit fabric of medium stretchiness.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams – 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

### Main fabric:

1. Back – cut 1 on fold
2. Front – cut 1
3. Sleeve – cut 2
4. Front inset – cut 2

### INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Serge the neckline edge on the front, press onto wrong side, and topstitch. Make and baste pleats (fold bulk towards bottom).
2. Pin front insets together, right sides facing, insert the front in between, and sew the shaped edge. Turn the inset right side out, straighten, and baste together along raw edges.
3. Cut or use ready-made bias tape, 4 cm wide and the length equal to the back neckline + 4 cm. Fold bias tape in half lengthwise, right side out, and press. Pin bias tape onto the back neckline from the right side and sew. Fold the bias tape onto the wrong side and topstitch onto the main piece along the seam.
4. Sew shoulder and side seams, press towards the back, and serge.
5. Sew sleeve seam, press towards the back, and serge. Sew sleeves into armholes, matching notches. Serge and press.
6. Serge hem allowance and sleeve hem, fold inside onto wrong side, and topstitch.

Congratulations – your t-shirt are finished! :)