

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.


5248 Short Chemise / Nightdress with Straps

Recommendations on fabric: natural or mixed silk material 150 cm (59-60 in.) width.

You will also need: ribbon or lace for the trim around cups.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: 1 cm for all seams.

Main fabric:

1. Upper Back – cut 1 on fold
2. Lower back – cut 2
3. Outer front cup – cut 2
5. Lower front – cut 1 on fold

Trim:

4. Inner front cup – cut 2

6. Back facing – cut 1
7. Shoulder strap – cut 2

INSTRUCTIONS:

1. Sew the center lower back seam. Serge the seam and press toward the left. Sew the lower and upper backs together. Serge the seam and press upward. Topstitch the seam allowances to the upper back.
2. Sew the darts on the outer and inner cups. Pin the cups right sides together and sew along the top and center edges. Turn right side out and press. Topstitch trim to the upper edges. Sew the cups to the lower front at the marks.
3. Sew the side seams.
4. Sew the shoulder straps to the back at the placement marks. Sew the back facing, right sides together, to the upper back. Turn under and press. Slipstitch the side edges of the back facing to the side seam. Topstitch.
5. Try on the chemise, check the length of the shoulder straps, and tack them to the garment front.

Congratulations, your nightdress is ready! :)