

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.


5428 Trousers with decorative belt

Recommendations on fabric: lightweight natural or mixed fabrics.

You will also need: iron-on interfacing, 2 buttons, decorative cord and zip 20 cm long.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowance: 1 cm for all seams, 2 cm for the hem.

Main fabric:

1. Front – 2 pieces
2. Back – 2 pieces
3. Front facing – 1 piece
4. Back facing – 1 piece
5. Back belt – 2 pieces
6. Front belt – 2 pieces

Fusible interfacing:

1. Front facing – 1 piece

2. Back facing – 1 piece
3. Back belt – 2 pieces
4. Front belt – 2 pieces

INSTRUCTIONS:

1. Apply the interfacing to the wrong side of the front facing, back facing, back belt and the front belt.
2. Join the front and the back belt across the right-side seam; press the seam open. Mark and make buttonholes in the right-side seam and in the center of the back belt. Cut decorative cord; topstitch the cord to the belt side edge. With right sides inside, pin the top and the under waistbands together; stitch around the belt leaving an opening in the top seam. Clip into the corners, turn the belt right side out and press. Topstitch the belt upper edge 0,5 cm below the edge.
3. Neaten the side edges, inside leg and the crotch edges of the garment. Stitch the side seams leaving a zipper opening in the left seam and the lower splits unstitched. Press the seams open. Topstitch the lower splits.
4. Stitch the inside leg seams; press them open. Stitch the crotch seam.
5. Insert the zip.
6. Join the front and back facing across the right-side seam; press the seam open. Neaten the facing inner edge. With the facing uppermost, stitch the facing to the garment upper edge. Under-stitch facing next to the seam.
7. Neaten the trousers lower edge, press the seam allowances under. Topstitch.
8. Sew buttons on the garment back center seam and on the right-side seam.

Congratulations, your trousers are ready! :)